



GAM Product #TS6100 Rosco Product #206 36100 0120




FILM/FX™ Loop water effect

## PRODUCT DESCRIPTION

SX4® Loop Tray

- For theme parks, display & theatrical applications
- Slides into SX4<sup>®</sup>Case mounted in ETC Source Four™
- Over 40 pattern loops available off-the-shelf
- Custom pattern loops available
- Integrated speed control and reverse switch -Integrated control can be used with a dimmer for mastering a group of SX4<sup>®</sup> units and for control from a light board.
- Pattern loop life span is 4,000 hours of continuous use ideal for theme park and retail applications

The SX4<sup>®</sup>Loop Tray is designed to fit into the SX4<sup>®</sup> Case which is attached to an ETC Source Four<sup>™</sup> fixed focus Ellipsoidal spotlight (see SX4<sup>®</sup>Case Specifications). The Loop Tray will accept a continuous loop pattern. The speed and direction of the loop are varied with on board controls and the speed can also be controlled from a dimmer. With a large number of off-the-shelf effects using GAM FX/Loops you can quickly create a variety of different projected images.




## PRODUCT SPECIFICATIONS

Dimensions:	
Wide:	11.31 in. (28.7 cm.)
Height:	11.25 in. (28.5 cm.)
Deep:	3.0625 in. (7.7 cm.)
Weight :	3 lbs.,5 oz. (1.44 kgs.)
With SX4 <sup>®</sup> Case:	9 lbs., 10 oz. (4.28 kgs.)
Finish:	Matte black paint
Power Draw:.	5 amp at 120v with our
	fixed 12VDC Transformer

Moving clouds, rain, snow, fire, water ripples, water falls, stars and so much more are as easy as selecting the appropriate FX/Loop from your catalog. The SX4<sup>®</sup> has been used on Broadway, in operas, film and television productions, special events, retail store displays, anywhere that a special lighting effect is required. Reliable, efficient, long-life and intuitive features set the SX4<sup>®</sup> projection system apart from all other choices.






## **PRODUCT NUMBER**

TS6100 / 206 36100 0120 SX4®, Loop Tray Analog - 120v TS6102 / 206 36100 0240 SX4®, Loop Tray Analog - 230v TS6100WHT / 206 36101 0120 SX4® (white), Loop Tray - Analog - 120v TS6102WHT / 206 36101 0240 SX4® (white), Loop Tray - Analog - 230v TS6100FS / 206 36110 0120 SX4® + Shutters, Loop Tray - Analog - 120v TS6102FS / 206 36110 0240 SX4® + Shutters, Loop Tray - Analog - 230v TS6100FSWHT / 206 36111 0120 SX4® + Shutters (white), Loop Tray - Analog - 120v TS6102FSWHT / 206 36111 0240 SX4® + Shutters (white), Loop Tray - Analog - 230v TS6210 / 206 36150 0000 SX4®, Tray Only - Loop TS6210WHT / 206 36151 0000 SX4®, Tray Only (white) - Loop TS6111 / 206 36200 0120 SX4®, DMX Loop Tray (24v PSU not included) TS6111FS / 206 36210 0120 SX4® + Shutters, DMX Loop Tray (24v PSU not included) TS6211 / 206 36250 0000 SX4®, Tray Only - DMX Loop TS6211WHT / 206 36251 0000 SX4®, Tray Only (white) - DMX Loop







## SX4® FILM/FX LOOP DESIGNS

