

GAM LAMPCHek™ INSTRUCTIONS

1. To check for lamp continuity (incandescents only), plug the light fixture lead into the female end of the GAM LampChek™. The lamp is working if the green pilot light comes on.
2. If the indicator does not show continuity, then you need to first check the lamp (bulb) to be sure that it is not burned out. If the bulb is good then you have a wiring problem.

