



A division of **ROSCO**
www.gamonline.com



GAM Product #RFRF777
Rosco Product #854 07777 0000

PRODUCT INSTRUCTIONS

YOU ARE HANDLING REAL FIRE WHEN YOU USE THE GAMTORCH™! USE CAUTION AT ALL TIMES!

Be aware of automatic fire sprinkler heads that may be in the area. Always be careful not to get flame too close to costumes, scenery, people's hair or other flammable objects. Use the GAMTorch™ only in approved venues where all safety precautions concerning fire are observed, and permits have been obtained (if applicable). Use only where there is proper ventilation and exhaust. The GAMTorch™ is intended for professional use only.

OPERATING INSTRUCTIONS

Before using the real flame GAMTorch™, check the safety release latch to ensure it's working properly.

TO CHECK SAFETY RELEASE LATCH [4]:

Pull down Flame Containment Sleeve [4] and hold Safety Release Latch [5] over Latch Button [7] on handle. Fire Chamber [3] should remain in the exposed position as long as safety release latch is held. Release Safety Release Latch [5] and observe that the Flame Containment Sleeve [4] completely shrouds the Fire Chamber [3] and the Containment Lid [1] snaps over the top of the Fire Chamber [3]. This action is instant, taking less than one second.

IF SAFETY RELEASE LATCH IS MALFUNCTIONING, DO NOT USE THE GAMTORCH! CONTACT GAMPRODUCTS, INC. FOR SERVICE.

Only after checking that the Safety Release Latch [5] is functioning properly, proceed to load GAMFuel™ pellets into the Fire Chamber [3]. Load one to four pellets, depending on size of flame and duration desired. Do not load more pellets than needed. Be sure to hold down Safety Release Latch [5] while loading Fire Chamber [3]. After loading Fire Chamber [3], secure GAMFuel™ pellets with Retaining Spring [2]. Refer to detail drawing on right. Conceal the chamber by releasing the Safety Release Latch [5]. The GAMTorch™ is now loaded and ready for use.

When you are ready to use the GAMTorch™, slide the Flame Containment Sleeve [4] down and grip the Safety Release Latch [5] firmly. Be sure to hold the Safety Release Latch [5] over Latch Button [7]. Use a lighter or match to ignite the GAMFuel™ in the Fire Chamber [3]. Long fireplace matches or 'extended' matches are ideal for this purpose. Light the GAMTorch™ approximately 30 seconds before a full flame is desired.

GAMFuel™ pellets will burn for approximately 15 minutes, depending on the ventilation conditions and flame height can be as much as 16 in (40 cm). Exercise extreme caution when in use! Dispose of spent fuel pellets carefully, making sure they are fully extinguished. Dump fuel pellets in pan with a small amount of water before disposal. Store GAMFuel™ pellets at temperatures below 1550 F (680 C).

